


Local TFTP Update Operations


You can update the phone firmware by observing the following operations:

1. Start up the computer and use a wireless network adapter to connect to the wireless network
The computer's IP address must be assigned to the same segment as the phone's IP address
2. As shown in the following figure, save the four update files to the same folder



3. At the phone, access **(Menu)→Misc→Local TFTP Update**, and then press the left soft key **(Update)**
Ensure the phone has enough battery power or is connected to the charger


4. At the computer, double click the "fwupgrade.exe" file to display the "Phone List" window:



5. Highlight the IP address of the intended phone and press the <Update> button to initiate the TFTP update process (in the example, the "172.18.37.240" IP address is selected)



6. When the update is complete, the window will prompt you. The current status of the phone will be displayed in the "Selected Phone Info" column



The phone will decompress the downloaded package and display "decompressing". After the decompression, the TFTP update will be complete; the phone will be switched off automatically

The updated firmware will take effect after you switch the phone on



Note: If errors occur during firmware download, the phone will keep using the original firmware. Restart the phone and repeat TFTP update operations to update the phone firmware

If errors occur during firmware decompression, restart the phone to resume the decompression; the phone will display "decompressing"