

TICOM

TECHNICAL INTELLIGENCE COMMUNICATIONS

Issue #2, March 2005

<http://www.iirg.net/~ticom/zine/> - email: ticom@iirg.net



This issue brought to you with help from Magic Hat #9

CONTENTS:

- ◆ Frequency Counter Logging to a PC - Pg. 1
- ◆ Bell System Special Services Interexchange Customer Handbook
WORD (Work Order Record & Details) Description - Pg. 3
- ◆ Editorial - Pg. 8

Frequency Counter Logging to a PC

Back when the first decent handheld frequency counters came out that were suitable for SIGINT operations, they lacked the features of current models. I used one of the Radio Shack counters with some success despite the lack of capture and hold features. Of course, it was much easier to use as a passenger in a vehicle than as a driver. Optoelectronics then came out with their "Scout" model that was specifically designed for this sort of thing. It also had a \$450 price tag. Many hardcore SIGINT hackers went and bought one to have fun with. Among the nice things about the Scout was that it had a 400 frequency memory, the capability to download frequency hits to a PC, and the ability to reaction tune an Icom or AOR receiver to the frequency it detected. The price tag however, kept it out of the range of most hobbyists. Optoelectronics still makes different models of the Scout, and they are still as expensive as they were ten years ago.

Other companies have started making frequency counters that feature the capability to automatically tune receivers to the frequency they detect. One such company is Aceco, whose products are also sold under other names. I came across one of their "RF Finders", the FC3002, at a local electronics shop for about half the price of the Optoelectronics Scout. It too was capable of automatically tuning an Icom or AOR receiver, and it does an admirable job with my Icom R-10. The feature it didn't have was memory storage of frequency hits. I figured that since it had a serial port and I had enough old laptops

lying around, there would be no problems with automatic frequency hit logging. I should also note that Optoelectronics at one time made a stripped-down version of the Scout that was basically intended for reaction-tuning receivers, and also lacked the memory storage of its big brother. You might come across one at a hamfest somewhere, and the information in this article also applies to that unit.

These frequency counters have a sub-mini speaker jack that is a TTL serial port. The frequency data can be sent out in either Icom's CI-V, or AORs command format; depending on what brand of receiver you are using with it. Of the two, the AOR format is the one that is the easiest for a person to read without software translation. The Aceco FC3002 has a switch on the front labeled "COM". Simply switch it to the "AOR" setting, and you'll be set. You will then need a TTL/Serial converter. For this article I used an Optoelectronics Optolynx. You may want to build your own if you are on a budget. TTL/Serial converters are a simple enough project, and on the next page is an example of an inexpensively-built one found on the net.. You will also need a PC of some sort running a terminal program at 9600 baud 8N1. The old Compaq in the picture was what I had handy, but I could have dug out a TRS-80 Model 100 and used that if so inclined. The equipment list when I was done looked like this:

- ◆ Aceco FC3002 Frequency Counter
- ◆ Optoelectronics Optolynx
- ◆ 24" patch cord, 1/8" miniature speaker plugs on each end
- ◆ sub-mini to 1/8" speaker plug adapter (the jack on the counter is a sub-mini)
- ◆ 9-pin "D" Serial Cable
- ◆ Old Compaq laptop running terminal software (Telix); 9600 baud, 8N1

After equipment assembly, simply turn everything on, set the frequency counter to reaction tune mode (On the Aceco, push the "FUNCTION" button until "HOLD" on the display starts flashing.), boot up the PC, and load the terminal software. At this point, you will want to test it with a transmitter to make sure it's working. Key up, and you should see the frequency of your transmitter displayed on the screen in the format of M0000000 where the 0000000 is the frequency. From there you can simply activate an ASCII text download on your terminal software, and all your frequency hits will be logged to disk.





5. WORD Document Changes Due to Divestiture

The WORD document will continue to show end-to-end design for inter-LATA circuits installed before January 1, 1984 and will include the overall IC Circuit ID as well as the BOC special access Circuit ID.

In the divested environment, however, the WORD document is changed from the current standard format to provide new information required for the provisioning of access service. Since the divested Bell Operating Companies (BOCs) are responsible only for access circuits from the Network Interface (NI), at the end user's location, to the Point of Interface (POI), at the Inter-exchange Carrier's Point of Presence (POP), the BOC WORD document will reflect only that portion of the overall circuit. Therefore, the SSC or STC receives only the design and Circuit ID for the access circuit. The IC has the overall service design and Circuit ID and is responsible for cross-referencing to the access circuit. A sample WORD document reflecting the mature, or post-divestiture, environment is provided.

In cases where the BOC is under contract to ATTCOMM for provisioning functions, separate WORD documents for each portion of the end-to-end service are issued. A WORD document is provided for the access circuit that the SSC or STC controls, as well as for the inter-exchange service the SSC or STC is controlling for ATTCOMM.

D1 and D2 1N5818 Diodes



CI-V to RS-232 Converter
from <http://www.qsl.net/kd6uu/icomci.html>

SPECIAL SERVICE WORK AUTHORIZATION

1 [CKT 41/IBTS/12345] /SW 6 [A STLSMO01] 8 --Z 15 [STLSMO22] LEASE 4
 ORD SLS123456 5 [-001 SUPP A] 7 [ACTN A] [CAC SSR9XD2] 8 MCO STLSM009TRO 9
 10-CUST ABC CORP 17 [CUS 123] 18 [CCON 201-221-3272] 19 [ACNA XXX] 20 IMC 201-555-4722
 16-BTN 201-221-4722 21-SA 100 N. BROADWAY, ST. LOUIS 63102
 22-CLO SLS331234 001 OF 23 [ORD TYPE N] 24
 27-RCLO SLS123456 001
 30-RO SLS123456
 CRO 33 36
 [ORIG/TEL RDB/201-221-5344]
 38-PREVIOUS CLO : CLO NBR DD ACTN
 [001 SLS200200002] [01-01-83] A 39B
 39 39A
 WORK DESCRIPTION AND NOTES: 42
 MATURE DIVESTITURE ENVIRONMENT WORD
 25-DD 01-01-84 IAD 26
 28-PTD 12-30-83 SWC 29
 31-FCD 12-27-83 WOT 32 12-25-83 32
 34-DVA 12-25-83 RID 35 12-22-83 35
 EX1 37 EX2
 EX3 EX4 40
 [OCO 123 STLSM009TRC 314-247-5555]
 [CCO 444 STLSM011AEC 314-247-1212]
 41

43-ITEM ACTN A Z [CD 002] [TD 005] [CKT ID : INDEX 41/IBTS/12345] /SW
 001 0 44 45 46 47

48-DISTRIBUTION
 STS/1,R33/1,R12/1

49-1104 [CO SWSL] 50 [DSG NR RDB/314-555-1212] 51 [ISS 002/11-04-83] 52 [PG W001-002] 53

SPECIAL SERVICE WORK AUTHORIZATION (CONTINUED)

1 [CKT 41/IBTS/12345] /SW 6 [A STLSMO01] 2 --Z 3 [STLSMO22] LEASE 4
 ORD SLS123456 5 [-001 SUPP A] 7 [ACTN A] [CAC SSR9XD2] 8 MCO STLSM009TRO 9
 10-CUST ABC CORP 15 17 [CUS 123] 11-RRI 15 MSC N-12 PRO SSM-13 RSP-14
 16-BTN 201-221-4722 [CCON 201-221-3272] [ACNA XXX] [IMC 201-555-4722] 20

AGENT AND CONTRACTUAL INFORMATION:

41 1104 50 [CO SWSL] 51 [DSG NR RDB/314-555-1212] 52 [ISS 002/11-04-83] 53 [PG W002-002]

NOTICE
 Not for use or disclosure outside the
 sponsoring Regional Bell Operating
 Companies except under written agreement.

NOTICE
Not for use or disclosure outside the
sponsoring Regional Bell Operating
Companies except under written agreement.

SPECIAL SERVICE WORK AUTHORIZATION - WA

- | | |
|--|--|
| *1. Circuit Identification
(In Common Language) | 28. Plant Test Date |
| **2. A Location | 29. Scheduled Work Completion |
| **3. Z Location | 30. Related Order |
| 4. Lease (when a facility equipment is leased
from another company) | 31. Frame Continuity Date |
| 5. Order Type & Number | 32. Wired & Office Tested |
| 6. Item & Item Supplement Indicator | 33. Complete with Related Order |
| 7. Activity Type
A-Add
D-Disconnect, etc. | 34. Designed, Verified & Assigned Date |
| 8. Circuit Access Code | 35. Records Issue Date |
| 9. Maintenance Control Office | 36. - Originator (Name & Tel. No.) |
| 10. Customer | 37. Optional Due |
| 11. Rebate Required Interval in Hours | 38. Previous Circuit (Layout)
-CLO Number
-Due Date
-Activity Type |
| 12. Minimum Service Charge
-Y (If applicable)
-N (If not applicable) | 39. CLO Number |
| 13. Protection Required
- SSM (Special Safeguarding Measures)
- SSP (Special Service Protection) | 39A. Due Date |
| 14. Restoration Priority | 39B. Activity Type |
| 15. Type & Direction of Pulsing | 40. Overall Control Office |
| 16. Bill to Number | 41. Circuit Control Office |
| 17. Customer Code | 42. Work Description & Notes |
| 18. Customer Contact Tel. No. | 43. Item No. of Order |
| 19. Access Customer's Name Abbreviation | 44. Activity Type |
| 20. Inter-Exchange Carrier's Maintenance Tel. No. | 45. Circuit Details |
| 21. Service Address | 46. Test Details |
| 22. Circuit Layout Order | 47. Circuit Identification |
| 23. # of Items (associated with CLO - if more than 1) | 48. Distribution (Specifies the No.
of copies and locations where word is sent) |
| 24. Order Type
- N (New)
- C (Change) etc. | 49. Broadcast Date |
| 25. Due Date | 50. Issuing Company Code |
| 26. Inventory Availability Date | 51. Designer & Designer Tel. No. |
| 27. Related Circuit Layout Order | 52. Issue & Issue Date |
| | 53. Page Number |
| | 54. Wired & Office Tested |
| | 55. Records Issue Date |

*1 REFER TO BSP 795-402-100

**2. AND 3. REFER TO BSP 682-400-100 TABLE A & B

SPECIAL SERVICE CIRCUIT DETAILS

(1) [CKT 41/IBTS/12345] /SW (6) [A STLSMO01] (37) --Z (3) [STLSMO22] LEASE-(4)
 (5) [ORD SLC123456] -001 [SUPP A] ACTN A [CAC SSR9XD2] (8) MCO [STLSMO09TRO] (9)
 CUST ABC CORP-(10) (16) (7) (11) [RRI 15] [MSC N] [PRQ SSM] (13) RSP-(14)
 (15) [BTN 201-221-4722] [CUS 123] [CCON 201-221-3272] [ACNA XXX] (12) [IMC 201-555-4722] (19)
 (20) [CLO SLS331234 001 OF] (21) (17) (18) (19)
 (22) N/*LOCN, EQPT AND FAC [FRAME ID] [UNIT] SV Z-A A-Z MISC
 STLSMO021
 (25) [NCI 4WLA2XXX] 4 + 7.0 16.0 F21/11D
 51/-59633-EF/4AB/01 SARTS
 NON/OT/CT/N/22/ +7.0/ 16.0 SARTS
 MTM2030B 01111.05 31 4 + 7.0 10.5 F21/A228
 MT44111A CS/12345678
 A TO B/RU1; 12.00 DB/
 RU2; L OFF; 2 SL; 6 HT;
 7 BW; 12.40 DB/600 ZOUT/
 RV =NOR, RV/T =RV/T
 (26) OWNER = ATIX
 (27) STLSMO021 F21/J22
 75 26NL 1201 XT 1.0 R0982 DB04.2
 75 26NL 1202 XR +1.0 R0982 DB04.2
 -XC BSMT EQPT RM 100 N. BROADWAY BP41/42
 25 19NL 12 XT R0099 DB00.3
 25 19NL 22 XR R0099 DB00.3
 1104 [CO SWSL] [DSG NR RDB/314-555-1212] [ISS 002/11-04-83] [PG C001-002]
 (28) (29) (30) (31) (32)

SPECIAL SERVICE CIRCUIT DETAILS (CONTINUED)

(1) [CKT 41/IBTS/12345] /SW (6) [A STLSMO01] (37) --Z (3) [STLSMO22] LEASE-(4)
 (5) [ORD SLC123456] -001 [SUPP A] ACTN A [CAC SSR9XD2] (8) MCO [STLSMO09TRO] (9)
 CUST ABC CORP-(10) (16) (7) (11) [RRI 15] [MSC N] [PRQ SSM] (13) RSP-(14)
 (15) [BTN 201-221-4722] [CUS 123] [CCON 201-221-3272] [ACNA XXX] (12) [IMC 201-555-4722] (19)
 (22) N/*LOCN, EQPT AND FAC [FRAME ID] [UNIT] [SV] [Z-A] [A-Z] MISC
 NCTE-(34) (17) (23) (24) (38) (33)
 8D29CABA
 GR 6.9/PT 7.0/
 EQ=359A/A1C3D14
 SC (35)
 [NCI 4WLA2XXX 10TH FLR TEL RM 100 N. BROADWAY BP25/26]
 [SCA XYZ CORP] [100 N. BROADWAY, ST. LOUIS] 201-221-1234 (36B)
 (36) (36A)
 (39) [1 /19GA/ /22GA/ /24GA/ /26GA/1.0 /BT
 2 /19GA/0.1 /22GA/ /24GA/ /26GA/ /BT
 1104 [CO SWSL] [DSG NR RDB/314-555-1212] [ISS 002/11-04-83] [PG C002-002]
 (28) (29) (30) (31) (32)


SPECIAL SERVICE CIRCUIT DETAILS (CD)

1. Circuit Identification
2. A Office Location
3. Z Office Location
4. Lease
5. Order Type & Number
6. Supplement Indicator
7. Activity Type
8. Circuit Access Code
9. Maintenance Control Office
10. Customer
11. Rebate Required Interval
12. Minimum Service Charge
13. Protection Required
14. Restoration Priority
15. Bill to Number
16. Customer Code
17. Customer Contact Tel. No.
18. Access Customer's Name Abbreviation
19. Inter-Exchange Carrier's Maintenance Tel. No.
20. Circuit Layout Order
21. # of Items (associated with CLO)
22. Locations, Equipment & Facilities
23. Frame Identification
24. UNIT (contains the number of the unit assigned for each hard-wired component)
25. Network Channel Interface Code
26. Owner (of FAC/EQPT, when leased from a company other than the BOC)
27. CLLI
28. Broadcast Date
29. Issuing Company Code
30. Designer & Designers Telephone Number
31. Issue & Issue Date
32. Page Number
33. Transmission Levels from Z-A and A-Z
34. Network Channel Terminating Equipment
35. Network Channel Interface Code and Point of Presence (POP)
36. Station Customer's Name
- 36A Station Customer's Address
- 36B Station Customer's Contact Tel. No.
37. Type & Direction of Pulsing
38. Signal & Voice Path
39. Local Cable Makeup.

NOTICE

Not for use or disclosure outside the sponsoring Regional Bell Operating Companies except under written agreement.

One of the Reasons Why Real Hackers Check Out Used Bookstores:



I was searching one of my regular used bookstore haunts a few days ago, and found this little gem in the "technical" section next to two copies of the DuPont Blasters Handbook (the definitive guide for the practical applications of high explosives). I already had a copy of the Blasters Handbook (also purchased at a used bookstore), so I bought this instead. This is the third Bell System publication that I have acquired at a used bookstore, and the latest of I can't recall how many decent technical publications.

The morals of this story are as follows:

- There are good reference materials out there that you won't find on the fucking Internet.
- Turn off the damn computer once and a while.
- Go outside and explore the real world.
- Go learn something.